

Welcome

Write in the rain.

Film underwater.

Capture a racecar roaring by at 200 mph.

Less than a year ago, these were only dreams. The shoptalk of our labs and offices — and the hopes of our community.

But passion, collaboration and an endless drive for exploration put these capabilities (and many more) in your hands today.

We are all explorers at heart, compelled to Never Settle.

The OnePlus 13 unleashes that spirit.

A Hasselblad triple-camera system with 4K Dolby Vision, meaningful AI features, and IP68/69 ratings provide the possibilities to engage with and experience your world like never before.

At the core, the lighter-than-light OxygenOS 15 delivers our fastest and smoothest experience yet.

From touch to technology, every element of the OnePlus 13 has been thoughtfully considered, crafted and calibrated together with you. All with one goal in mind:


That every time you pick up your phone, you have the same reaction as we do:


Wow.

Share your experience, collaborate and co-create with other OnePlus users by joining the OnePlus Community.

Never Settle.

■ Button description





1 EN: Earpiece Speaker
FR: Haut-parleur supérieur
DE: Hörmuschel-Lautsprecher
ES: Altavoz del auricular
FI: Kuulokkeen kaiutin
IT: Altoparlante superiore
NL: Luidspreker bovenkant
SE: Högtalare (vid örat)
PL: Głośnik słuchawki
RO: Difuzor cască
CZ: Reprodaktor sluchátka
BG: Говорител на слушалката
DK: Ørehøjttaler
GR: Ηχείο ακουστικού
EE: Kuular
HR: Zvučnik slušalice
HU: Beszédhangszóró
LT: Ausinės garsiakalbis
LV: Austiņas skaļrunis
PT: Altifalante de auricular
SK: Reprodaktor slúchadla
SI: Zvočnik v slušalki

2 EN: Front Camera
FR: Caméra avant
DE: Frontkamera
ES: Cámara frontal
FI: Etukamera
IT: Fotocamera anteriore
NL: Frontcamera
SE: Främre kamera
PL: Aparat przedni
RO: Cameră foto frontală
CZ: Přední fotoaparát
BG: Предна камера
DK: Frontkamera
GR: Μπροστινή κάμερα
EE: Esikaamera
HR: Prednji fotoaparāt
HU: Elülső kamera
LT: Priekinė kamera
LV: Priekšējā kamera
PT: Câmara frontal
SK: Predný fotoaparát
SI: Sprednja kamera

3 EN: Ultrasonic fingerprint sensor
FR: Capteur d'empreintes digitales à ultrasons
DE: Ultraschall-Fingerabdrucksensor
ES: Sensor ultrasónico de huellas dactilares
FI: Ultraääni-sormenjälkitunnistin
IT: Sensore di impronte digitali a ultrasuoni
NL: Ultrasone vingerafdruksensor
SE: Ultraljuds fingeravtryckssensor
PL: Ultradźwiękowy czujnik linii papilarnych
RO: Senzor de amprentă cu ultrasunete
CZ: Ultrazvukový snímač otisků prstů
BG: Ултразвуков сензор за пръстови отпечатащици
DK: Ultralyds-fingeraftrykssensor
GR: Αισθητήρας δακτυλικών αποτυπωμάτων υπερήχων
EE: Ultraheli-sõrmejäljeandur
HR: Ultrazvučni senzor otiska prsta
HU: Ultrahangos ujilenyomat-érezékelő
LT: Ultragarsinis pirštų atspaudų jutiklis
LV: Ultraskaņas pirkstu nospiedumu sensors
PT: Sensor ultrasónico de impressões digitais
SK: Ultrazvukový snímač odtlačkov prstov
SI: Ultrazvočni senzor prstnih odtisov

4 EN: Speaker
FR: Haut-parleur
DE: Lautsprecher
ES: Altavoz
FI: Kaiutin
IT: Altoparlante inferiore
NL: Luidspreker
SE: Högtalare
PL: Głośnik
RO: Difuzor
CZ: Reprodaktor
BG: Високоговорител
DK: Højtaler
GR: Ηχείο
EE: Kõlar
HR: Zvučnik
HU: Hangszóró
LT: Garsiakalbis
LV: Skalrunis
PT: Altifalante
SK: Reprodaktor
SI: Zvočnik

5 EN: Volume
FR: Volume
DE: Lautstärke
ES: Volumen
FI: Äänenvoimakkuus
IT: Volume
NL: Volume
SE: Volym
PL: Głośność
RO: Volum
CZ: Hlasitost
BG: Сила на звука
DK: Lydstyrke
GR: Ένταση ήχου
EE: Helitugevus
HR: Glasnoća
HU: Hangerő
LT: Garsumas
LV: Skatums
PT: Volume
SK: Hlasitost
SI: Glasnos

6 EN: Power Sleep/Wake
FR: Mise en veille/sortie de veille
DE: Ruhezustand/Wachzustand einschalten
ES: Activar/desactivar potencia
FI: Virran lepo/herätys
IT: Sospensione/Riattivazione
NL: Aan/Uit Slapen/Activeren
SE: På/av-knapp
PL: Włącznik/uśpienie/budzenie
RO: Inactivitate/reactivare alimentare
CZ: Tlačítko deaktivace/probuzení
BG: Заспиване за енергия/събуждане
DK: Strømstyring og slumretilstand/Vækning
GR: Λειτουργία αδράνειας/αφύπνισης
EE: Toide Uinutus/äratus
HR: Mirovanje/aktiviranje
HU: Alvó üzemmód/aktiválás
LT: Miego režimas / pažadinimas
LV: Miega režīms / Aktivizēšana
PT: Ligar Dormir/Acordar
SK: Tlačidlo napájania
SI: Vkllop, stanje pripravljenosti/preklop iz stanja pripravljenosti

7 EN: USB Type-C port
FR: Port USB type C
DE: USB-Anschluss Typ C
ES: Puerto USB tipo C
FI: USB Type-C -portti
IT: Porta USB di tipo C
NL: USB Type-C-poort
SE: USB-C-port
PL: Gniazdo USB-C
RO: Port USB tip C
CZ: Port USB typu C
BG: USB Type-C порт
DK: USB-port type-C
GR: Υποδοχή USB Type-C
EE: USB Type-C pesa
HR: USB Type-C priključak
HU: USB Type-C csatlakozó
LT: USB „Type-C“ jungtis
LV: C tipa USB ports
PT: Porta USB tipo C
SK: Port USB typu C
SI: Priključek USB Type-C

8 EN: Alert Slider
FR: Alert Slider
DE: Alert Slider
ES: Alert Slider
FI: Alert Slider
IT: Alert Slider
NL: Alert Slider
SE: Alert Slider
PL: Alert Slider
RO: Alert Slider
CZ: Alert Slider
BG: Alert Slider
DK: Alert Slider
GR: Alert Slider
EE: Alert Slider
HR: Alert Slider
HU: Alert Slider
LT: Alert Slider
LV: Alert Slider
PT: Alert slider
SK: Alert Slider
SI: Alert Slider

9 EN: Nano SIM Slot
FR: Emplacement carte nano SIM
DE: Nano-SIM-Steckplatz
ES: Ranura Nano SIM
FI: Nano SIM -paikka
IT: Slot Nano SIM
NL: Nanosimkaartsleuf
SE: Kortplats för nano-SIM-kort
PL: Gniazdo kart nano SIM
RO: Fantă Nano SIM
CZ: Slot pro nano-SIM
BG: Слот за Nano SIM
DK: Nano-SIM-slot
GR: Υποδοχή nano SIM
EE: Nano SIM-i pesa
HR: Nano SIM utor
HU: Nano-SIM-foglalat
LT: Nano SIM lizdas
LV: Nano SIM kartes slots
PL: Gniazdo kart nano SIM
PT: Ranhura nano-SIM
SK: Slot na kartu nano SIM
SI: Reža za kartico nano SIM

■ Learn More

For more information, please download the complete guide on

<https://service.oneplus.com/global/user-manual>.

This manual is for reference only, the actual product shall prevail.

The information is subject to change without notice.

This manual is published by OnePlus. OnePlus may correct any misprints, errors, and inaccuracies in the manual or improve its apps and/or devices at any time it deems necessary without any notice. Such changes will be applied in the later versions of this manual. All images in this manual are for reference only and may differ from the actual device and UI.

For environmental reasons this package does not include a charger. This device can be powered with most USB power adapters and a cable with USB Type-C plug.